

# Honda Pilot/Odyssey Sway bar instructions

1. Remove upper sway bar link nut
2. Install Traxda bracket, pointed up
3. Reinstall upper sway bar nut.

