

# Honda Pilot Rear Instructions

1. Put on jack stands safely
2. Remove rear wheels
3. Remove lower control arm bolt at spindle. 17mm wrench size
4. Loosen 17mm bolt on control arm at frame
5. Swing down control arm, remove spring



- 6.
7. Remove bump stop snubber with 14mm socket on 6" extension

8. Install rear spacer into chassis



9. Re install bump stop snubber



10. Then put spring with isolator onto spacer
- a. Order should go -- chassis -> spacer -> isolator -> spring .

11. Using floor jack , raise control arm back into position



12. Re-install bolt at the spindle
13. Reinstall wheels and lower to the ground
14. **Tighten control arm bolts at the frame when the vehicle is on the ground.** Normal weight should be on the wheels or shortened bushing life may result.