



TRAXDA
Lift Kits - Made in USA

Toll free: 888-660-5892
email: info@traxda.com

SAFETY WARNING!
Always use the correct tools, and wear safety goggles. We **STRONGLY** recommend installation by a licensed mechanic on a properly secured locking lift.

TIRE FITMENT ADVICE

The best way to ensure proper tire fitment is to install the kit before purchasing your wheels and tires. Always test fit tires and wheels before purchasing.

VEHICLE RIDE WARNING!

Trucks with lift or level kits installed have a higher center of gravity. Aggressive and sudden direction changes may cause a tip over.

406016 Chevrolet Tahoe & Suburban/GMC Yukon/Cadillac Escalade 6-Lug Rear Spring Spacer Kit

This kit contains:

2 - Rear Spring Spacers

Instructions

Warranty card

Stickers



Installation Tips

Always use caution handling ABS or wheel sensor wiring. Avoid tension of any kind on wiring harness as this may cause damage or failure.

1. Trucks are often not level side to side from the factory. Please measure before installation.
2. Re-torque all hardware to manufactures specifications
3. When aligning, to get the best tire wear use our supplied specifications. OEM specifications are for trucks with stock wheels and tires. Larger tires will wear differently.
4. All instructions are written with vehicle on a 2-post lift with tires removed.

Support rear differential with jack. Starting on one side disconnect ABS wires so they can droop. Disconnect sway bar and remove lower shock bolt. Lower jack and remove spring. Position TRAXDA spacer over insulator on top of spring as shown (see illustration). Reinstall spring and reconnect all components. Repeat installation on other side.

