

Front

1. Pull windshield wiper arms
2. Pull cowl cover - 3 pieces
3. Disconnect firewall padding from bottom of strut brace bar
4. Remove strut brace bar
5. Remove 3 nuts on the top of each strut
6. Remove axle nut - IMPORTANT
7. Remove 12 mm bolt holding brake line on
8. Remove sway bar link at the strut
9. Remove two lower strut bolts
10. CAREFUL - parts will be unsupported - remove from vehicle

11. Install Traxda strut spacer onto strut.
12. Rotate strut hat 180 degrees
13. Reinstall strut with lower bolts.
14. Re attach sway bar link
15. Reattach brake line
16. Re attach 3 bolts on strut and reinstall all other parts.

Alignment - use Specialty Products #81260 for Camber adjustment if needed

Align to OEM specs

Rear

1. Remove rear seats
2. Remove upper interior panels
3. Remove lower interior panels
4. Remove insulated padding
5. Remove 2 nuts from top of strut
6. Remove lower strut bolt

7. Put Traxda spacer plates on top of strut, reinstall

8. Install padding
9. Install lower interior panels
10. Install upper panels.

For rear camber adjustment use Specialty Products #81250 12mm camber bolt on upper inside suspension arm if needed.