

Step 1

Lift truck using jackstands or a hoist (hoist is preferred), and remove wheels, starting with the passenger side.

Step 2

Remove OEM U-bolts on one side of rear (Do not do both at the same time for safety reasons.)

Step 3

Place Traxda Block between U-bolt and springs.

Step 4

Install Traxda U-bolt in place of OEM U-Bolt.

Step 5

Repeat steps 2-4 for other side.

Step 6

Align to stock specs. **CAMBER** adjustment is reach from inside the truck. Limit to about 12 degree without mods.