

Traxda 906030

FRONT

1. Pull windshield wiper arms
2. Pull cowl cover
3. Remove windshield wiper motor
4. Remove 3 nuts on the top of each strut
5. Remove axle nut - IMPORTANT
6. Remove 12 mm bolt holding brake line on
7. Remove 10 mm bolt holding ABS wire
8. Remove sway bar link
9. Remove two lower strut bolts
10. CAREFUL - parts will be unsupported - remove from vehicle
11. Install Traxda strut spacer on to strut.
12. Rotate strut hat 180 degrees
13. Reinstall strut with lower bolts
14. Attach supplied Traxda sway bar link
15. Reattach brake line
16. Reattach 3 bolts on strut and reinstall all other parts.

Alignment - use #81260 for Camber adjustment if necessary

REAR

1. Remove lower shock bolt
2. Remove lower strut bolt
3. Loosen rear suspension arm bushing
4. Place Traxda coil spring spacer on top of spring, on top of spring isolator
5. Shock extender goes on bottom of shock

Reverse the steps during reinstallation

Align to stock specs.

Make sure to tighten rear suspension bushing when vehicle is on the ground. Tightening while in the air could result in premature bushing wear.