

TRAXDA 602040 Pacifica Minivan lift kit

FRONT

1. Pull windshield wiper arms
2. Pull wiper arm cowl cover
3. Disconnect firewall padding from bottom of strut brace bar
4. Remove strut brace bar
5. Remove 3 nuts on the top of each strut
6. Remove axle nut - IMPORTANT to avoid over extending axle when installing.
7. Remove 12 mm bolt holding brake line on
8. Remove sway bar link at the strut
9. Remove two lower strut bolts
10. CAREFUL - parts will be unsupported - remove from vehicle
11. Install Traxda strut spacer onto strut.

12. Reinstall strut with lower bolts.
13. Re attach sway bar link
14. Reattach brake line
15. Re attach 3 nuts on strut and reinstall all other parts.

REAR

1. Remove lower control arm bolt at outside at spindle.
2. Loosen inner bolt on control arm
3. Lower arm down.
4. Install rear spring spacer with stud down through hole in control arm.
5. Reinstall arm.
6. Tighten control arm bolts when vehicle is on the ground.

Alignment - use Specialty Products #81260 for Camber adjustment if needed
Align to OEM specs

Front strut mount with windshield wiper cowl removed



Rear Suspension arm hanging down. Stud goes through red hole

